

# OPERATION MANUAL

## 1.SUMMARIZE






The meter is a stable multimeter with 40mm LCD display, driven by battery. It's widely used on measuring DCV, ACV, DCA, ACA, resistance, capacitance, diode, transistor, continuity test ,temperature auto power off /on and LCD back – light . It's an ideal tool for lab, factory and family.

## 2. SAFETY NOTE

The meter meets the standards of IEC1010. Read the operation manual carefully before operation.


- 1. Do not input limit over-ranged.
- 2. The voltage below 36V is safety. To avoid electric shock, check whether the test leads are connected correctly, whether the insulation is good when measuring over 36DCV or 25ACV.
- 3. Remove the test leads when changing function and range.
- 4. To select correct function and range, beware of error operation.;
- 5. Do not operate the meter if battery case and back cover is not fixed.
- 6. Do not input voltage when measuring resistance.
- 7. Remove test leads from test point and turn off the power before replacing battery and fuse.

## 8. SAFETY SYMBOLS

“” EXISTS DANGEROUS VOLTAGE, “” GND, “” DUAL INSULATION  
“” THE OPERATOR MUST REFER TO THE MANUAL , “” LOW BATTERY

## 3.CHARACTERISTIC

### 1. GENERAL

- 1-1. Display :LCD displaying.
- 1-2. Max. displaying: 1999 (3 1/2digit) auto polarity indication.
- 1-3. Measuring method: dual slope A/D conversion.
- 1-4. Operation uninterruptable power.
- 1-5. Using panel testing technology
- 1-6. Sampling rate: approx. 3 times/second.
- 1-7. Over range indication: the MSD displays “OL” .
- 1-8. Low battery indication: “” appears.
- 1-9. Operation environment: (0~40)℃, R.H.<80% .
- 1-10. Power: 9V×1 (NEDA1604/6F22 or equivalent model) .
- 1-11. Size: 175×93×55mm
- 1-12. Weight: approx. 400g (including battery) .
- 1-13.Accessories:operation manual ,holster, gift box, 20A test leads, K type thermocouple TP01 and 9V battery.

### 2. TECHNICAL CHARACTERISTIC

- 2-1. Accuracy:±(a%×rdg+d) at (23±5)℃, R.H.<75%, one year guaranteed from the production date.

### 2-2. TECHNICAL DATA

#### 2-2-1. DCV

RANGE	ACCURACY	RESOLUTION
200mV	±(0.5%+3)	100uV
2V		1mV

20V	±(0.5%+3)	10mV
200V	±(0.5%+3)	100mV
1000V	±(0.8%+10)	1V

Input resistance: 5MΩ at mV range , other ranges: 10 MΩ

Overload protection: 250V DV or AC peak value at 200mV range.

1000V DC or AC peak value at other ranges.

#### 2-2-2. ACV TRUE RMS

RANGE	ACCURACY	RESOLUTION
2V	±(0.8%+5)	1mV
20V		10mV
200V		100mV
750V	±(1.2%+10)	1V

Input resistance: 10MΩ

Overload protection: 1000V DC or AC peak value

Frequency response : (40~1000) Hz (for standard sine wave and triangular wave )

Display: True RMS (just for reference when over 200Hz at other waves.)

In AC750V range, you can test AC380V and AC220V commercial power after press the “HOLD”key.

#### 2-2-3.DCA

RANGE	ACCURACY	RESOLUTION
200uA	±(0.8%+10)	0.1uA
2mA		1uA
20mA		10uA
200mA	±(1.2%+8)	100uA
20A	±(2.0%+5)	10mA

Max. input volt drop: 200mV;

Max. input current: 20A (the test time should be within 10 seconds)

Overload protection: 0.2A/250V; 20A/250V fast-melt fuse

#### 2-2-4.ACA

RANGE	ACCURACY	RESOLUTION
20mA	±(1.0%+15)	10uA
200mA	±(2.0%+5)	100uA
20A	±(3.0%+10)	10mA

Max. measuring volt drop: 200mV

Max. input current: 20A (the test time should be within 10 seconds)

Overload protection: 0.2A/250V; 20A/250V fast-blown fuse

Frequency response: (40~1000) Hz (for standard sine wave and triangular wave )

Display: True RMS (just for reference when over 200Hz at other waves.)

#### 2-2-5. RESISTANCE (Ω)

RANGE	ACCURACY	RESOLUTION
200Ω	±(0.8%+5)	0.1Ω
2kΩ	±(0.8%+3)	1Ω
20kΩ		10Ω
200kΩ		100Ω

2MΩ	±(0.8%+3)	1kΩ
20MΩ	±(1.0%+25)	10kΩ

Open voltage: less than 0.7V

Overload protection: 250V DC and AC peak value

NOTE: at 200Ω range, the test leads should be short-circuit, and measure the down-lead resistance, then, subtract from the real measuring.


WARNING: DO NOT input any voltage at resistance range for safety!

#### 2-2-6. CAPACITANCE (C)

RANGE	ACCURACY	RESOLUTION
2nF	±(5.0%+40)	1pF
20nF	±(2.5%+20)	10pF/100pF
200nF		10pF/100pF
2uF/20uF/200uF		100nF
2000uF	±(5.0%+10)	1uF
20mF		10uF

Overload protection: 36V DC or AC peak value

#### 2-2-7.DIODE AND CONTINUITY TEST

Range	Displaying value	Test condition
	Positive voltage drop of diode	The positive DC current is approx. 1mA , negative voltage is approx. 3V
	Buzzer sounds , the resistance is less than 30Ω	open voltage is approx. 3V

Overload protection: 250V DC or AC peak value

Warning: DO NOT input any voltage at this range for safety!

#### 2-2-8. Triode hFE test

Range	Display range	Test condition
hFE NPN or PNP	0~1000	Basic current is approx.10uA,Vce is approx.3V

#### 2-2-9. TEMPERATURE(℃)

Range	Accuracy	Resolution
(-20~1000)℃	< 400℃±(1.0%+5) ≥ 400℃±(1.5%+15)	1℃

Sensor: K-type thermocouple with banana plug

## 4. OPERATION

### 4.1 Front panel description

- 1. Model
- 2. LCD: display the measured value .
- 3. Shine diode: the alert for continuity testing.
- 4. range knob: selecting measuring function , range and power on/off.
- 5. 20A current test jack
- 6. “+” pole jack of testing 200mA current.
- 7. “—” pole of capacitance. and GND.
- 8. “+” pole jack of volt, resistance and diode.
- 9. Transistor test jack : transistor testing input terminal.
- 10. LCD backlight/automatic shutdown switch

See the fig.



4.2 DCV MEASUREMENT

- 1.Insert the black test lead to “COM” jack, the red one to V/Ω jack.
- 2.Set the range knob to a proper DCV range, connect the test leads across to the circuit under tested, the polarity and voltage of the point which red lead connect will display on LCD.

NOTE:

- 1.If the measured voltage is unsure beforehand, should set the range knob to the highest range, then, switch to a proper range according to the displayed value.
- 2.If LCD displays “OL” , it means over range, should set the range knob to a higher range.

4.3 ACV True RMS MEASUREMENT

- 1.Insert the black test lead to “COM” jack, the red one to V/Ω jack.
- 2. Set the range knob to a proper ACV range, connect the test leads across to the circuit under tested.

NOTE:

- 1.If the measured voltage is unsure beforehand, should set the range knob to the highest range, then, switch to a proper range according to the displayed value.
- 2.If LCD displays “OL” , it means over range, should set the range knob to a higher range.

4.4 DCA MEASUREMENT

- 1.Insert the black test lead to “COM” jack and the red one to “mA” jack (max. 200mA), or insert the red one to “20A” jack (max. 20A) .
- 2.Set the range knob to a proper DCA range, connect the test leads across to the circuit under tested, the current value and polarity of the point which red lead connect will display on LCD.

NOTE:

- 1.If the measured current is unsure beforehand, should set the range knob to a higher range, then, switch to a proper range according to the displayed value.
- 2.If LCD displays “OL” , it means overrange, should set the range knob to a higher range.
- 3. When measuring 20A.. Continuously measuring large current may heat the circuit, affect the accuracy, eve damage the meter.

4.5 ACV MEASUREMENT

- 1.Insert the black test lead to “COM” jack and the red one to “mA” jack (max. 200mA), or insert the red one to “20A” jack (max. 20A) .
- 2.Set the range knob to a proper ACA range; connect the test leads across to the circuit under tested.

NOTE:

- 1.If the measured current range is unsure beforehand, should set the range knob to the highest range, then set to a proper range according to the displayed value.
- 2.If LCD displays “OL” , it means overrange, should set the range knob to a higher range.
- 3. Pay attention to measure 20A.. Continuously measuring large current may heat the circuit, affect the accuracy, eve damage the meter.

4.6 RESISTANCE MEASUREMENT

- 1.Insert the black test lead to “COM” jack and the red one to “V/Ω” jack.
- 2.Set the range knob to a proper resistance range, connect the test leads across to the resistance under measured.

NOTE:

- 1.If the resistance value being measured exceeds the max value of the range selected, LCD displays "OL", thus, should set the range knob to a higher range. When the resistance is over 1M Ω , the meter may take a few seconds to stabilize. This is normal for high resistance readings.

- 2.When input terminal is in open circuit, overload displays.
- 3.When measuring in-line resistance, be sure that power is off and all capacitors are released completely.


4.7 CAPACITANCE MEASUREMENT

- 1.Insert the red test lead to “V/Ω” terminal and the black one to “COM” jack.
- 2.Set the range knob to a proper capacitance range, connect the test leads to the capacitor under measured (note: the polarity of red test lead is “+”) .

NOTE:

- 1.If the capacitance range under measured is unsure beforehand, should set the range knob to the highest range, then, set to a proper range according to the displayed value.
- 2.If LCD displays “OL” , it means over range, should set the range knob to a higher range.
- 3.Before measuring, LCD display might not be zero, the residual reading will be decreased gradually and could be disregarded.
- 4.When measuring large capacitance, if creeps seriously or break capacitance, LCD will display some instability value.
- 5.Discharge all capacitors completely before capacitance measurement to avoid damage.
- 6.UNIT: 1uF =1000nF 1nF=1000pF

4.8 DIODE AND CONTINUITY TEST

- 1.Insert the black test lead to “COM” terminal and the red one to V/Ω jack( Note: the polarity of red test lead is “+” ).
- 2. Set the range knob to “ ” range, connect the test leads to the diode under measured, reading is the approximation of the diode positive volt drop.
- 3.Connect the test leads to two points of the measured circuit, if buzzer sounds, the resistance is lower than approx.30 Ω .

4.9 TRIODE hFE

- 1.Set the range knob to hFE.
- 2.Verify the type of the transistor is NPN or PNP, insert the emitter, basic and collector to the proper jack on test accessory.

4.10 AUTO POWER-OFF AND LCD BACKLIGHT ON

After power on ,LCD displays “APO” ,mean the meter is in automatic power off mode , With rotate the knob in 15 minites and the figure changing , The meter is in nonautomatic power off mode .Press “HOLD” key to power on the meter , when “APO” isn’t showing on LCD ,the meter is in nonautomatic power off mode .Shortly press “HOLD” key to turn on/off the “HOLD” function , Long press “HOLD ” key to turn on/off the backlight .


4.11 TEMPERATURE MEASUREMENT

Insert the cathode of thermocouple’s cold end to “COM” jack and anode to “V/Ω” terminal, put the working end on or in the tested object, temperature value can be read on LCD in Celsius.


5.MAINTENANCE

DO NOT try to verify the circuit for it’s a precision meter.

- 1.Beware of waterproof, dustproof and shockproof.
- 2.Do not operate and store the meter in the circumstance of high temperature, high humidity, and flammability, explosive and strong magnetic field.

- 3.Use the damp cloth and soft solvent to clean the meter, do not use abrasive and alcohol.
- 4.If do not operate it for a long time, should take out the battery.
- 4-1.When LCD displays “ ” symbol, should replace the battery as below:
- 4-1-1.Take out the holster and drop out the battery case.
- 4-1-2.Take out the battery and replace a new one. It’s better to use alkalescence battery for long time use.
- 4-1-3.Fix the battery case and take on the holster.

6. If the meter does not work properly, check the meter as following:

CONDITIONS	WAY TO SOLVE
NO DISPLAYING	●Power is off ●Replace battery
 symbol displays	●Replace battery
NO CURRENT INPUT	●Replace fuse
BIG ERROR	●Replace battery